


Ring Around Instructions



After Un-packing the Ring Around.

Remove any clear protective film covering the plastic housing.

Insert the correct adaptor for your country into the 12v DC Switch Mode power supply, plug the adaptor into a power supply and turn on at the mains socket.

To operate use the switch on the unit, or plug a remote switch, *(not provided)*, into the 1/4" jack socket.

The Bell chimes will work after pressing one of the on switches. *(Note that the chimes start speed remains faster for as long as one of the switches is pressed)*

Press the switch once for **ON** and press again for **OFF**.

Please Note:

The rotation of the chimes can be reversed by using the direction control slider switch.



TFH Special Needs
5-7 Severnside Business Park
Severn Road
Stourport-on-Severn
DY13 9HT

www.specialneedstoys.com - tel: 01299 827820 fax: 827035 E: info@tfhuk.com