



# BOUNCER CHAIR HARNESS

## PLEASE NOTE

THIS HARNESS IS FOR COMFORT,  
SUPPORT AND CORRECT POSITIONAL  
BOUNCING,  
IT IS **NOT** A SAFETY RESTRAINT.

## CONTENTS



Unclip the black webbing  
from the main harness.  
Remove the 4 side clips  
slide a tri glide onto each  
webbing as shown in fig (A)  
next refit a clip to each  
webbing see fig (B)  
now thread each end  
through the tri glide see fig (C)  
You can now clip the  
harness pad in place,  
To adjust,  
move the webbing  
through the tri glides.